

**IMPORTANT** - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.

**⚠ DISCONNECT THE MAIN LINE BEFORE WIRING SECONDARY CONNECTORS.**

## IN-LINE UNIT INSTALLATION

### INTEGRAL DRIVER (120 / 277V)

### DIMMING TRIAC/ELV (15%), 0-10V (1%), LUTRON HI-LUME® (1% EcoSystem™ / 1% 2-WIRE)

A- PREPARE CEILING WITH ANCHOR SCREWS (SEE TABLE ON PAGE 3).

B- SEE DETAIL:

1- PASS THE WIRES THROUGH THE CANOPY.


2- MAKE NECESSARY WIRE CONNECTIONS (SEE WIRING DIAGRAM) USING TWIST CONNECTORS (NOT INCLUDED).

**FOR D10 AND D2B DIMMING:** WIRES MUST BE RUN THROUGH A SEPARATE KNOCKOUT HOLE FROM JUNCTION BOX.


3- INSTALL UNIVERSAL CROSSBAR USING 8-32 PHILLIPS SCREWS (INCLUDED) AND THE CANOPY USING 8-32 PHILLIPS SCREWS (INCLUDED).

C- INSTALL THE ALUMINUM EXTRUSION TO THE CEILING USING 8-32 PHILLIPS SCREWS (NOT INCLUDED) INTO THE ANCHOR SCREWS.


D- CONNECT THE LIGHTING FIXTURE USING THE QUICK CONNECTORS (INCLUDED) AND SNAP LIGHTING FIXTURE AND/OR COVER PLATE BACK INTO THE ALUMINUM EXTRUSION.



DETAIL 1




## WIRING DIAGRAM\*




\*for reference only

SURFACE ANCHOR POINTS DISTANCE

SOLO UNIT 4'



SOLO UNIT 8'



\*Units over 4' nominal length require a centered anchor.

ANCHOR POINTS FOR LINEAR SURFACE ALL CONFIGURATIONS		
Nominal length	Actual length	Anchor qty
04'	3'-10 3/4" (1.187m)	2
08'	7'-10 3/4" (2.407m)	3